

Product Guide

User and Maintenance Information

IMPORTANT INFORMATION:
Please save this product guide.

CUSTOMER SERVICE:

United States

PO Box 2
Ulster Park, NY 12487
Office hours: 9-5 EST
Phone (800) 777-4244
Fax (800) 336-5948
(845) 572-3468

www.CommunityPlaythings.com
Sales@CommunityPlaythings.com



F151 Introductory Set

Recommended Use

Unit blocks are a popular means of learning. They are a medium for expressing rhythm, pattern and design and are one of the best instructional playthings. Children love the feel of the smooth, rounded wood, and never tire of the endless variety of constructions they can create.

⚠ WARNING

▲ This product is intended for use by children of immature judgment, therefore supervision is required at all times.

⚠ CAUTION

▲ For indoor use only; water and dirt will spoil these blocks.

If your shipment is incomplete, please call Customer Service.

Accessories

A14 Storage Chest or A60 Block Cart are ideal for storage

Contents of F151 Carton

Block Name	Qty
Unit	24
Double Unit	15
Quadruple Unit	4
Half Unit	6
Pillar	8
Half Pillar	8
Double Pillar	2
Triangle	2
Small Triangle	4
Ramp	4
Large Cylinder	4
Small Cylinder	4
Big Bldg Board	0
Roof Board	4
Unit Arch	2
Elliptical Curve	0
Quarter Cir. Arch	2
Quarter Circle	2
Half Roman Arch	2
Intersection	0
Side Road	0
Total	97

Number of Cartons per set

CAT #	Description	F151	G475	G476
G431	Preschool	1	1	0
G461	¼ School	1	1	1
G462	Half School	2	2	2
G464	School Set	4	4	4

Maintenance

Periodically inspect for cracks, breaks, loose parts, missing parts, and/or malfunctions. Remove the product from service when any condition develops that might make operation unsafe.

Cleaning

If your blocks become dirty, you may want to wash them. If so, use a minimum of soap and water. Too much water may cause warping or rotting.

If washing doesn't remove enough dirt from your blocks, try *lightly* sanding them. Blocks won't stack well if heavily sanded.

Construction

Blocks have rounded corners and are manufactured from solid maple. Building and Roof Boards are durable, non-warping medium density fiberboard.

User Modifications

We are not responsible for modifications made by customers to our products in the field without our supervision, testing, or evaluation.

Ordering Parts

To order replacement parts, contact Customer Service with a description of the part(s) needed.

Use only replacement parts supplied by Community Playthings.