

# Product Guide

## User and Maintenance Information

**IMPORTANT INFORMATION:**  
Please save this product guide.

### CUSTOMER SERVICE:

#### United States

PO Box 2  
Ulster Park, NY 12487

Office hours: 9-5 EST

Phone (800) 777-4244

Fax (800) 336-5948

(845) 572-3468

www.CommunityPlaythings.com

Sales@CommunityPlaythings.com



# A637 Canopy

## Recommended Use

Recommended for children ages 1-8.

### ⚠ WARNING

- ▲ This product is intended for use by children of immature judgment, therefore supervision is required at all times.
- ▲ Keep away from fire.
- ▲ This accessory is intended for use on the following Community Playthings products only:

A631 Large Clear Table

A632 Large Teal Table

## Assembly

Equipment comes in a single carton.

The carton contains:

1. Two uprights
2. One Crossbar with hooks
3. Three plain cross bars
4. Canopy fabric

### If your shipment is incomplete, please call Customer Service.

1. Fit the two uprights to the end of the table and secure by tightening the knobs.
2. Fit the three cross bars with the black strips up, using the middle notch on both ends.
3. Attach the canopy fabric.
4. Fit the cross bar with hooks.

**NOTE:** there are three height setting possibilities.

## Operation

The canopy will add color and atmosphere. The bar with hooks provides convenient storage for aprons and toys, and supports the pulley and funnel in the Extras Kit.

## Accessories

**Extras Kit** includes an extra length of clear hose, a funnel, a pulley and a mesh bag to further extend the play possibilities.

## Maintenance

Periodically inspect for cracks, breaks, loose parts, missing parts, and/or malfunctions. Remove the product from service when any condition develops that might make operation unsafe.

## Cleaning

Clean wood with soap and water. Disinfectants can be used. Dry well as too much water will harm the finish of the wood. Wash the fabric by hand only, do not machine wash. Use a mild detergent and warm water. Rinse fabric thoroughly, and air dry.

## Construction

The wooden components are of a solid hardwood or durable hardwood plywood coated with a clear nontoxic finish. Fabric is 60% High UV Polypropylene 40% UB Polyester for long life. The hardware is corrosion resistant zinc plated steel.

## User Modifications

We are not responsible for modifications made by customers to our products in the field without our supervision, testing, or evaluation.

## Ordering Parts

To order replacement parts, contact Customer Service with a description of the part(s) needed and the ID Code from the product.

**Use only replacement parts supplied by Community Playthings.**

