

# Product Guide

## User and Maintenance Information

**IMPORTANT INFORMATION:**  
Please save this product guide.

### CUSTOMER SERVICE:

#### United States

PO Box 2

Ulster Park, NY 12487

Office hours: 9-5 EST

Phone (800) 777-4244

Fax (800) 336-5948

(845) 572-3468

[www.CommunityPlaythings.com](http://www.CommunityPlaythings.com)

[Sales@CommunityPlaythings.com](mailto:Sales@CommunityPlaythings.com)



# W338 Two 11" Ramps and Two 22" Ramps W337 Two 22" Outlast Ramps W336 Two 11" Outlast Ramps

## Recommended Use

The Ramps enhance the play value of Outlast Blocks and can be used in water play.

For ages 3 and older.

### ⚠ WARNING

- ▲ This product is intended for use by children of immature judgment, therefore supervision is required at all times.
- ▲ Children should not build structures above their shoulder height.

### ⚠ CAUTION

- ▲ The Outlast Ramps and Blocks are part of an open-ended, large muscle play system. Children can place this product in combination with other objects to create an injury hazard.
- ▲ To prevent injury, caregivers and staff must familiarize themselves with these materials before giving children access to them.

## Operation

Ramps come in two sizes and are compatible with Outlast Blocks and Flow Pans. Their innovative, interlocking feature makes it possible to create completely sturdy structures on uneven ground.

## Assembly

Your ramps come fully assembled and ready to use. Check your shipment:

W336 contains two 11" Ramps.

W337 contains two 22" Ramps.

W338 contains two 11" and two 22" Ramps.

**If your shipment is incomplete, please call Customer Service.**

## Accessories

The Outlast Flow Pan adds an extra level and water flow possibilities.

## Maintenance

Acetylated wood weathers a natural silver grey if left untreated outdoors.

If you prefer the original look, scrub with a bleach or detergent solution. When dry, apply a tinted, nontoxic penetrating stain, then apply a nontoxic mildewcide to minimize mildew growth.

Periodically inspect for splinters, broken or loose parts, and/or malfunctions. Remove from service when any condition develops that might make operation unsafe.

## Cleaning

Mud and dirt can be removed with scrub brush and water. Over time outdoors, surfaces may blacken with mildew. Remove with detergent or a bleach solution.

## Construction

The wooden components are manufactured from long lasting acetylated wood and finished with a water based stain. All edges and corners are rounded for safety and ease of cleaning.

End grain is protected by plastic guards. Stainless steel hardware is used throughout and plastic components are formulated to ensure long life in outdoor environments.

## User Modifications

We are not responsible for modifications made by customers to our products in the field without our supervision, testing, or evaluation.

## Ordering Parts

To order replacement parts, contact Customer Service with a description of the part(s) needed and the ID Code from the product.

**Use only replacement parts supplied by Community Playthings.**

