

Product Guide

User and Maintenance Information

Important Information: Please save this product guide.

V43 Nursery Rocking Boat

Recommended Use

The Nursery Rocking Boat provides opportunities for teamwork, exercise and fun for up to four children at a time. When turned over, it can be used as a set of stairs. Recommended for children aged 2-6.

⚠ WARNING

- ▲ This product is intended for use by children of immature judgement, therefore supervision is required at all times.
- ▲ Use only on a level surface away from stairs.

⚠ CAUTION

- ▲ For indoor use only. This Rocking Boat is not waterproof.

Maintenance

Periodically inspect for cracks, breaks, and loose or missing parts. Remove the product from service when any condition develops that might make use unsafe.

Cleaning


Wipe the Rocking Boat with a damp cloth and a mild detergent. Do not use excessive water.

Construction

The wooden components are manufactured from solid maple finished with a clear nontoxic finish. All edges and corners are rounded for safety and ease of cleaning.

User modifications

We are not responsible for modifications made by customers to our products in the field, without our supervision, testing or evaluation.



Customer Service:

United States

PO Box 2
Ulster Park, NY 12487
Office hours: 9-5 EST
Phone (800) 777-4244
Fax (800) 336-5948
(845) 572-3468

www.CommunityPlaythings.com
Sales@CommunityPlaythings.com

