

Product Guide

User and Maintenance Information

IMPORTANT INFORMATION:
Please save this product guide.

Recommended Use

This mirror accessory is designed for use with the G28 Wall-Mounted Shelf. When mounted on the underside of a shelf over a changing table, the mirror captures a child's attention during changing. The mirror can also be attached to a wall or shelf where a mirror is desired.

⚠ WARNING

- ▲ This product is intended for use by children of immature judgement. Supervision is required at all times.

⚠ CAUTION

- ▲ For indoor use only. This accessory is not waterproof.

Assembly

Mirror accessory comes in a single carton.

The carton contains:

1. One Mirror accessory.
2. A bag containing mounting hardware.
3. This Product Guide.

If your shipment is incomplete, please call Customer Service.

Installation:

To attach the Mirror to a G28 Wall-Mounted Shelf, drive two screws into the pre-drilled holes on the underside of the second shelf as shown. (Figure A) Use the screws provided with your accessory.

To mount the mirror on a wall or older model shelving unit, mark the hole positions and pre-drill them

G282 Mirror for Wall Shelf

using a 1/8" (3mm) drillbit. Attach the mirror securely to a wall or shelf with fasteners appropriate to the wall or shelf construction.

⚠ WARNING

- ▲ The Mirror accessory must be properly mounted to a firm surface with appropriate hardware. The customer must assume full responsibility that it will be secure for the long term.

Maintenance

Periodically inspect for cracks, breaks, loose parts, missing parts, and/or malfunctions. Remove the product from service when any condition develops that might make operation unsafe.

Construction

The Mirror for Wall Shelf is a shatterproof, scratch resistant plastic mirror mounted on a solid maple block.

User Modifications

We are not responsible for modifications made by customers to our products in the field without our supervision, testing or evaluation.

Ordering Parts

To order replacement parts, contact your Customer Center with a description of the part(s) needed and the ID Code from the product.

Use only replacement parts supplied by Community Playthings.

CUSTOMER SERVICE:

United States

PO Box 2

Ulster Park, NY 12487

Office hours: 9-5 EST

Phone (800) 777-4244

Fax (800) 336-5948

(845) 572-3468

www.CommunityPlaythings.com

Sales@CommunityPlaythings.com



Figure A