

Product Guide

User and Maintenance Information

IMPORTANT INFORMATION:
Please save this product guide.

Recommended Use

Recommended for children ages 3-8. This kit offers a variety of accessories to enhance the learning possibilities and play value of Sand and Water play.

⚠ WARNING

▲ This product is intended for use by children of immature judgement therefore supervision is required at all times.

Check Shipment

Equipment comes in a single carton. The carton contains:

1. Length of clear hose
2. Pulley
3. Mesh Bag
4. Funnel

If your shipment is incomplete, please contact Customer Service.

Operation

The length of clear hose can be used as a siphon. It will attach to the flow pan hose and the funnel. The funnel can attach to the cross bar with hooks or to the side of the flow pan. It can also be suspended by three strings and set spinning. You can make some interesting sand designs this way. The pulley attaches to the cross bar with hooks and can be used to hoist buckets. A raised load can be secured using the hook on the canopy upright. Hook the mesh bag onto the cross bar to hold wet toys where they can drain back into the pan.

Maintenance

Periodically inspect for cracks, breaks, loose parts, missing parts, and/or malfunctions. Remove the product from service when any condition develops that might make operation unsafe.

Cleaning

These parts can be washed with soap or mild detergent and water. Disinfectants can be used.

Construction

The hose is clear Tygon tubing, plasticizer free. The pulley and funnel are tough plastic and the mesh bag is a durable polyester fabric.

Ordering Parts

To order replacement parts, contact Customer Service with a description of the part(s) needed and the ID Code from the product.

Use only replacement parts supplied by Community Playthings.

CUSTOMER SERVICE:

United States

PO Box 2
Ulster Park, NY 12487
Office hours: 9-5 EST
Phone (800) 777-4244
Fax (800) 336-5948
(845) 572-3468

www.CommunityPlaythings.com
Sales@CommunityPlaythings.com

